

Syncing With Alarm.com

Syncing the Wi-Fi Doorbell Camera with Alarm.com is simple and fast via the the Alarm.com customer app. Remember to use the customer's mobile phone during the syncing process.

1. Install the Doorbell Camera.
2. Ensure that the Doorbell Camera is flashing with a Red/Green alternating pattern.
3. Download the Alarm.com App and log into your account.
4. Go to the Doorbell Cameras tab and add A Doorbell Camera.
5. Name your Doorbell Camera.
6. Connect to Doorbell Camera's Temporary Wi-Fi Access Point (SkybellHD_#####). The app will instruct the user to connect to the doorbell camera's Wi-Fi network.
 - **iOS – leave the app and enter the *settings app*. Go to Wi-Fi and select the network named (SkybellHD_#####).**
 - **Android – do not leave the app; the Alarm.com app will detect the doorbell camera's network.**
7. Select the permanent Wi-Fi network for the doorbell camera.
8. The Doorbell Camera will sync. The Doorbell camera's LED will follow this pattern:
 - Double-Flash Orange (~30 seconds)
 - Alternating Blue/Green (~30 seconds)
 - Solid Green

Note: if the LED gets stuck on the double-flash orange mode then the incorrect Wi-Fi credentials were entered.